

Drilled and tapped swing arm M10. Cut M10 bolts to length and drilled and tapped heads M4. Fitted M4 allen screws so that only head projects. Ground the swing arm to allow the locknut to seat flat. Fitted wheel and adjusted chain, much improved adjustment with large bolts.

