

Tacho HT Pick up connections

(when fitting to Positive Earth machines)

Advertised
pick up for HT



YOUR pick up
for HT



Connection
reference

Pulse to Tacho head
-12volts from key switch
+12 from battery terminal